



REMOVE FOR ORIGINAL

**DIMENSIONS 'A' WHEN FITTING WITH F-22R1-08 BEARING SPACER
DIMENSIONS 'B' WHEN FITTING WITH F-22R1-09 BEARING TOP HAT BUSH**



SECTION A-A



**WHEN FITTING THIS DIFFERENTIAL EITHER THE F-22R1-08 BEARING SPACER, OR F-22R1-09 BEARING TOPHAT BUSH MUST BE USED
IF THE STANDARD DIFFERENTIAL BEING REPLACED HAS 2x38.13mm BEARINGS THEN USE THE F-22R1-08 BEARING SPACER
IF THE STANDARD DIFFERENTIAL BEING REPLACED HAS 1x38.13mm BEARING AND 1x41.00mm BEARING THEN USE
THE F-22R1-09 BEARING TOPHAT BUSH**

QUAIFE®
DESIGN AND DEVELOPMENT

THIS DRAWING OR DESIGN IS STRICTLY CONFIDENTIAL AND THE COPYRIGHT THEREIN THE EXCLUSIVE PROPERTY OF R.T. QUAIFE ENGINEERING LTD, AND MAY NOT BE USED, COPIED OR EXHIBITED WITHOUT THEIR WRITTEN PERMISSION

UNLESS OTHERWISE STATED: ALL DIMENSIONS IN MILLIMETERS	TOLERANCES DIMENSIONS: 0 PLACES: ±0.25 1 PLACE: ±0.2 2 PLACES: ±0.1
GENERAL SURFACE FINISH: 1.6	ANGLES: ±0.25°
SHEET 1 OF 2	SCALE 1:1 U.O.S.
ISSUE: 01 DATE: 8.10.09	RELEASE DATE:
DRAWN BY: J.P.D.	CHECKED BY:
MATERIAL:	
BLANK SIZE:	
HEAT TREATMENT:	
FINISH:	
DESCRIPTION: GENERAL ASSEMBLY	
PART No.: F-22R1-01	